Cocall 2 User Manual

First use - To access the system's option, *there must be no card in the reader*.
Cocall 2 has two audio sources : MP3(Micro SD port) and Audio input. To go from a source to another, use MENU and press on ◄◄/►► to select.

How to listen to MP3s ? - Insert a card into your Cocall and put the " On/Off " switch to " On ". The Cocall will start playing automatically. To play a different sound, press on ◄◄/►►. To put your Cocall on pause or on play, press on ►II/■

How to raise/lower the volume ? - Press and hold ◄◄/►► to adjust the volume.

How to recharge the battery ? - Plug your Cocall with the charger included. The screen will show in the right corner if your Cocall is fully charged or not.

How to change the lighting's duration? - Press on MENU and use ◄◄/►► to select BACKLIGHT in options. Note : When the backlight is off, you have to press on any button to make it light up again.

How to change the language ? - Press on MENU and use ◄◄/►► to choose the desired language.

How to change the reading mode ? - While the call is playing, press on MENU and select CYCLE MODE and press on MENU. Select the desired mode using ◄◄/►► and press on MENU to confirm. The recommended mode for hunting is REPEAT ONE (this mode only plays and repeat the call you have selected).

Principal menu interface - The principal menu has 4 applications.
Calendar, Music, Line in and system settings.

Use MENU and press on ◄◄/►► to select.