

COCALL-LINK

MODE D'EMPLOI



Model: LK2025-1

Produits Cocall inc. 148 Grande Allee O, Grande Riviere, Qc, G0C1W0,

CANADA - www.cocall.ca - Copyright © 2013 Produits Cocall inc. All rights reserved.

Inclus dans la boîte

- 1 x Cocall-Link
- 1 x Câble de charge USB-C
- 1 x Manuel d'utilisation
- 1 x bande de fixation.

SPÉCIFICATIONS		DÉTAILS
	Nom du produit	COCALL-LINK
	Modèle	LK2025-1
	Connectivité	Bluetooth + Wi-Fi
	Portée sans fil	Jusqu'à 75 m en forêt
	Portée maximale	Jusqu'à 150 m en ligne de vue dégagée
	Batterie	Lithium rechargeable interne 1500mAh
	Recharge	USB-C
	Lecteur mémoire	Micro-SD intégré
	Résistance	Résistant aux intempéries
	Compatibilité	Modèles COCALL depuis 2012
	Télécommande compatible	RC100M
	Application mobile	COCALL-HUNT
	Voyants DEL	Vert fixe / Vert clignotant / Bleu clignotant

Chargement

1. Branchez le câble USB-C au port de charge du Cocall-LINK.
2. Connectez l'autre extrémité à un port USB ou à un chargeur mural
3. Le voyant vert flash et reste allumé lorsqu'il est terminé de charger
(Temps de charge approximatif : 3 heures)

Connexion à l'application Cocall-Hunt

1. Activez le Bluetooth et le Wi-Fi sur votre téléphone.
2. Ouvrez l'application COCALL -HUNT.
3. Sélectionnez votre appareil COCALL-LINK
4. Appuyez sur connecte

Indicateur DEL

Le voyant DEL indique l'état du système :

- Vert clignotant lent: appareil actif
- Vert fixe : appareil recharger
- Vert clignotant : recharge en cours
- Bleu clignotant : mode jumelage pour la télécommande

Conseils d'utilisation

- Ne pas exposer l'appareil à une chaleur excessive.
- Ne pas immerger l'appareil dans l'eau
- Ne pas démonter ou modifier l'appareil.
- Garder l'appareil hors de portée des enfants.
- Éviter les impacts ou chutes importantes
- Débrancher le câble de recharge après utilisation.
- Utiliser uniquement des accessoires compatibles.
- Ne pas recharger l'appareil en dessous de -5 degrés celcius.
- Entreposer dans un endroit sec après utilisation.
- Recharger l'appareil au 3 mois pendant l'entreposage.

Support technique

Courriel : service@cocall.ca

Site web : www.cocall.ca

Téléphone : 1-877-374-5962

Garantie

1 an de garantie limitée.

Produits Cocall inc. garantie ce produit contre les défauts de fabrication pour une période d'une année. *Produits Cocall nc.* à l'obligation de réparer ou remplacer sous garantie le produit défectueux. Pour recevoir de la garantie sur ce produit, veuillez contacter notre service à la clientèle pour un numéro RMA, le produit défectueux doit être retourner à Produits Cocall inc. au frais du client avec une bref description du problème et une preuve d'achat incluant la date d'achat. La garantie ne couvre pas les produits endommager par accident, par négligence, par mauvaise utilisation ou par modification ou par le non-respect des règles de sécurité.

Application Mobile COCALL-HUNT

Utilisez le Cocall-LINK avec l'application mobile Cocall-Hunt
voici les codes QR pour le téléchargement.



Produits Cocall inc.
148 Grande Allee O, Grande Riviere, Qc, G0C1W0,
Phone : 1-418-385-5101
Email: service@cocall.ca
www.cocall.ca

COCALL-LINK

User Manual



Model: LK2025-1

Produits Cocall inc. 148 Grande Allee O, Grande Riviere, Qc, G0C1W0,

CANADA - www.cocall.ca - Copyright © 2013 Produits Cocall inc. All rights reserved.

What is in the box

- 1 x Cocall-Link
- 1 x USB-C wire
- 1 x user manual
- 1 x mounting strap

SPECIFICATIONS		DETAILS
 Product Name	COCALL-LINK	
 Model	LK2025-1	
 Connectivity	Bluetooth + Wi-Fi	
 Wireless Range (in forest)	Up to 75 m in forest conditions	
 Maximum Range (line of sight)	Up to 150 m in clear line-of-sight conditions	
 Battery	Internal rechargeable 1500mAh lithium battery	
 Charging	USB-C	
 Memory Reader	Integrated Micro-SD reader	
 Resistance	Weather-resistant	
 Compatibility	COCALL models since 2012	
 Compatible Remote	RC100M	
 Mobile Application	COCALL-HUNT	
 LED Indicators	Solid Green / Flashing Green / Flashing Blue	

Charging

1. Connect the USB-C cable to the charging port of the COCALL-LINK.
2. Connect the other end to a USB port or wall charger.
3. The green LED flashes while charging and remains ON once the battery is fully charged.
(Approximate charging time: 3 hours)

Connecting to the COCALL-HUNT Application

1. Enable Bluetooth and Wi-Fi on your phone.
2. Open the COCALL-HUNT application.
3. Select your COCALL-LINK device.
4. Press "Connect".

DEL indicator

The LED indicator shows the system status.:

- Slow flashing green: device active
- Solid green: battery fully charged
- Flashing green: charging in progress
- Flashing blue: RF remote pairing mode

Usage Tips

- Do not expose the device to excessive heat.
- Do not immerse the device in water.
- Do not disassemble or modify the device.
- Keep the device out of reach of children.
- Avoid heavy impacts or drops.
- Disconnect the charging cable after use.
- Use compatible accessories only.
- Do not charge the device below -5°C (23°F).
- Store the device in a dry location after use.
- Recharge the device every 3 months during storage.

Technical support

Courriel : service@cocall.ca

Site web : www.cocall.ca

Téléphone : 1-877-374-5962

Warranty

1 Year Warranty Limited

Produits Cocall inc. warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. *Produits Cocall's* obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. To obtain service under this warranty, you must obtain a Returned Material Authorization (RMA) number from *Produits Cocall* service center. Products must be returned to *Produits Cocall* service center with transportation paid by customer and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment, which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

COCALL-HUNT app

Use the Cocall-Link with the Cocall-Hunt mobile app;
here are the QR codes for downloading.



Produits Cocall inc.

148 Grande Allée O, Grande Rivière, Qc, G0C1W0,

Phone : 1-418-385-5101

Email: service@cocall.ca

www.cocall.ca